





# Instruction manual M-Light 24 SMD LED-light

EN



Art. 32055



www.KRAFTWERK.eu




Download Bedienungsanleitung / Téléchargement du mode d'emploi / Instructions download  
Descarga de la instrucción de uso / Download de instruções de operação / Download del manuale



www.KRAFTWERK.eu

128克铜版纸 105\*140mm



- A) 24 SMD LED
- B) USB charger socket
- C) Battery capacity indicator
- D) ON-OFF switch
- E) Brightness adjusting button
- F) Magnetic base

## Warnings and cautions



### WARNING:

A LIGHT NOT MARKED for OUTDOOR USE is to be used for INDOORS ONLY.  
Risk of electrical shock. Not for use near gas, combustible or explosive materials.  
Misuse can lead to FIRE or DEATH by electrical shock.  
Please read carefully and follow all directions before using.

- KEEP CHILDREN AWAY
- Fully insert plug into power source (100 - 240 V)
- Grasp plug, NOT CORD, to remove from outlet
- Don't use in or around tubs, showers, sinks, pools, hot tubs, or in a wet environment
- Do not operate light with wet hands
- DO NOT USE a damaged cord set
- Inspect light periodically
- Keep lamp away from hot objects
- DO NOT open, repair or modify



Waste electrical products should not be disposed of together with household waste.  
Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

- The battery can not be replaced
- The battery must be removed from the appliance before it is scrapped
- The appliance must be disconnected from the supply mains when removing the battery
- The battery is to be disposed of safely

## WARRANTY

We do not take responsibility for any damage caused by misuse or any use that is not in compliance with the safety standards described herein.



From date of purchase receipt  
**2 YEARS GUARANTEE**  
on material- or production-defects