

KRAFTWERK®



FAVORITE TOOLS SINCE 1979

Instruction Manual

Cordless drill/driver 10.8 V

Art. 32107





EN






WARNING:

DO NOT attempt to operate the tool until you have read and understood all instructions and safety rules contained in this manual. Failure to comply may result in accidents involving fire, electric shock, or serious personal injury. Save this owner's manual for future reference and review it frequently for safe operation.







1. Proper usage

The machine is intended for tightening and loosening screws as well as for drilling in wood, metal, ceramic and plastic.

2. Safety instructions and warnings

The equipment complies with the safety regulations required for electrical equipment.

Read through the instructions for use before starting up the equipment.

Improper use can lead to personal injury and property damage. Persons, who are not familiar with the instructions, may not operate the equipment.

Keep the instructions for use in safe custody.

Children and minors are not permitted to operate the equipment.

3. General Power Tool Safety Warnings

WARNING Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

1) Work area safety

a) Keep work area clean and well lit. Disordered or dark areas can lead to accidents.

b) Do not operate power tools in explosive environments with flammable liquids, gases or dust. Power tools create sparks which may ignite dust or fumes.

c) Keep children and other persons away while operating a power tool. Distractions can cause you to lose control.

2) Electrical safety

a) Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce the risk of electric shock.

b) Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.

c) Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.

d) Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges and moving parts. Damaged or tangled cords increase the risk of electric shock.

e) When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.

f) If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock.

3) Personal safety

a) Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.

b) Use personal protective equipment. Always wear eye protection. Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.

c) Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.

d) Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.

e) Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.

f) Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.

g) If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of dust collection can reduce dust-related hazards.

4) Power tool use and care

a) Do not overload the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.

b) Do not use the power tool if the switch is out of function. Any power tool that cannot be controlled by the switch is dangerous and must be repaired.

c) Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or placing power tools. Such preventive safety measures reduce the risk of starting the power tool unintentionally.

d) Store unused power tools out of reach of children and do not allow persons not familiar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of inexperienced users.

e) Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.

f) Use the power tool, accessories and drill bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.

5) Battery tool use and care

a) Recharge only with the charger specified by the manufacturer. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.

b) Use power tools only with specifically designated battery packs. Use of any other battery packs may create a risk of injury and fire.

c) When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects, that can make a connection from one terminal to another. Shorting the battery terminals together may cause burns or fire.

d) Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.

6) Service

a) let your power tool be repaired by a qualified service person using only original service/spare parts. This will ensure that the safety of the power tool is maintained.

4. Special safety instructions

• Hold power tool by insulated gripping surfaces, when performing an operation where the cutting accessory or fastener may contact hidden power lines. Cutting accessory and fasteners contacting a “live” wire may make exposed metal parts of the power tool “live” and could give the operator an electric shock.

• Use appropriate detectors to determine if utility lines are hidden in the work area or call the local electric company for assistance. Contact with electric lines can lead to fire and electric shock. Damaging a gas line can lead to explosion. Penetrating a water line causes property damage or may cause an electric shock.

• Switch off the power tool immediately when the inserted tool jams and blocks. Be prepared for high reaction torque that can cause a kickback.

The inserted tool jams when:

- the power tool is subject to overload or
- it becomes wedged in the workpiece.

• Hold the machine with a firm grip. High reaction torque can briefly occur while tightening in and loosening screws.

• Secure the workpiece. A workpiece fixed with clamping devices or in a vice is held more securely than by hand.

• Keep your workplace clean. Mixing of materials is particularly dangerous. Light metal dusts easily can burn or explode.

• Always wait until the machine has come to a complete stop before placing it down. The inserted tool can jam and lead to loss of control over the power tool.

• Do not open the battery. Danger of shortcircuiting. Protect the battery against heat, e. g., also against continuous sun exposure and fire. There is danger of explosion.

• In case of damage and improper use of the battery, vapours may be emitted. Provide for fresh air and seek medical help in case of complaints. The vapours can irritate the respiratory system.

• When the battery is defective, liquid can escape and come into contact with adjacent components. Check any parts concerned. Clean such parts or replace them, if required.

5. Description of symbols

Pay attention to all the signs and symbols shown in these instructions and on your tool.

Make a note of these signs and symbols. If you interpret the signs and symbols correctly, your work with the machine will be safer and better.



Important.



Read the instructions for use before starting the machine.



Wear safety goggles.



Wear ear protection.



Wear good quality, strong gloves.



Always use breathing apparatus when machining materials which generate dust.



Battery-packs are reusable resources



Li-Ion battery



Avoid continuous sun exposure



Do not throw into fire



Do not throw into water



Waste electrical equipment contains valuable materials and they do not belong to household waste.

We kindly ask you to help to protect the environment by returning this machine to a return point (if available) after reaching the end of its life.



Used batteries do not belong to household waste. There is the legal obligation to return batteries to appropriate recycling points.

6. Layout

1. Torque selector
2. Rotation selector switch
3. On/Off switch
4. Li-ion battery pack
5. Battery holder
6. Selector switch for 1st/2nd gear
7. Quick-change drill chuck
8. Battery charger
9. LED lamp
10. Integrated magnetic bit holder
11. Battery capacity indicator

7. Before starting the equipment

Be sure to read the following information before you use your cordless screwdriver for the first time:

1. Charge the battery pack with the supplied charger. An empty battery pack requires a charging time of approximately 100 min.
2. Only ever use sharp drill bits and driver bits which are suitable for the purpose and in flawless condition.
3. Always check for concealed electric cables and gas and water pipes when drilling and screwing in walls.

8. Operation

8.1 Charging the battery pack (B2-B3)

The battery is protected against total discharge. The integrated protective system will automatically switch off the machine when the battery is completely discharged. In this case the bit holder is not turning anymore.



Warning!

Don't use the ON/OFF switch any longer if the integrated protective system switched off the machine. This could lead to damage the battery.

1. Remove the battery pack (4) from the handle pressing the pushlock buttons (5) on the left and the right side.

2. Check that your mains voltage is the same as marked on the rating plate of the battery charger. Plug the mains plug of the charger (8) into the mains socket outlet. The green LED starts to flash.

3. Insert the battery (4) on the charger (8).

4. Under point 8.10 „ Indication of charger“ you find a table with the meanings of the LED-indication for the charger.

If the battery pack fails to become charged, please check whether there is voltage at the socket-outlet - whether there is proper contact at the charging contacts on the charger (8). If the battery still fails to become charged, please deliver the charger and the battery pack to our Customer Service Department. To ensure that the battery pack provides long service you should take care to recharge it promptly. You must recharge the battery pack when you notice that the power of the cordless screwdriver drops. Never fully discharge the battery pack. This will lead the battery pack to damage.

Attention! Recharge the battery at regular intervals (for example every 6 months).

8.2 Torque setting (B4)

The cordless screwdriver is fitted with a mechanical torque selector. The torque for a specific size of screw is selected with the set-collar (1). The correct torque depends on several factors:

- the type and hardness of material in question
- the type and length of the used screws
- the requirements to be applied on the screw connection.

The clutch disengages with a grating sound to indicate when the set torque is reached. Important! The tool must be at a standstill when you set the torque with the setting ring.

8.3 Drilling (B4)

For drilling purposes, move the set-collar to the

last step „Drill“. In this setting the slip clutch is inactive. The maximum torque is available in drilling mode.

8.4 Forward/Reverse switch (B5)

With the slide switch above the ON/OFF switch you can select the direction of rotation of the battery powered drill/screwdriver and secure it against being switched on unintentionally. You can choose between clockwise and anticlockwise rotation. To avoid causing damage to the gear box change the direction of rotation only when the tool is at standstill.

The ON/OFF switch is blocked when the slide switch is in centre position.

8.5 On/Off switch (B5)

Variable speed control is possible with the On/Off switch. More you press the switch, higher gets the speed of the battery powered drill/screwdriver.

Power up:

Press for starting the machine the ON/OFF switch (3) and hold down the button. The LED-light (9) lights up with slightly or completely pressed ON/OFF switch (3) and enables to illuminate the work area.

Power down:

Release the ON/OFF switch (3) for turning off the machine.

8.6 Battery capacity indicator (B1)

The 3 color LEDs are indicating the status of the battery capacity as soon as you press the ON/OFF switch (3).

All LEDs illuminate: The battery is fully charged.
The yellow and red LED illuminate: The battery has an adequate remaining charge.
Red LED: The battery is empty, recharge the battery.

8.7 LED lamp (B5)

The LED lamp (9) can be used in poor lighting conditions to illuminate the area to drill or screw. The LED lamp (9) will be lit automatically as soon as you press the ON/OFF switch (3).

8.8 Changing the tool (B6)

Important! Set the rotation selector switch (2) to its centre position whenever you carry out any work (for example changing the tool, maintenance work, etc.) on the cordless screwdriver.

- The cordless screwdriver is fitted with a quick change chuck (7) with an automatic spindle stop.

- Open the chuck (7). The chuck opening (a) must be big enough to hold the tool (drill bit or screwdriver bit).

- Select the suitable tool. Push the tool as deep as possible into the chuck opening (a).

- Tighten the chuck (7) and then check that the tool is secure.

8.9 Screwdriving

We recommend using self-centering screws (e.g. Torx screws, recessed head screws) designed for reliable working. Be sure to use a bit that matches the screw in shape and size. Set the torque, as described in these operating instructions, to suit the size of screw.

8.10 Indication on battery charger

Slide the battery on the charger. The red LED signalized that the battery is fully charged. If the charge status is terminated the red LED goes out and the green LED then lights constantly.

8.11 Changing from 1st gear to 2nd gear (B4/Pos.6)

Information: Push the gear switch 6 only when the machine is at stillstand. In first gear (gear switch 6 in position 1) you obtain a speed of about 400 rpm and a high torque. This setting is ideal for all screwing actions. In the second gear (gear switch 6 in position 2) you obtain a speed of about 1400 rpm for drilling operations.

8.12 Integrated magnetic bit holder (B.7-8)

The cordless drill/driver has an integrated magnetic bit holder (10) for ¼" (6.35 mm) bits.

To use them you have to remove the quick-change drill chuck (7) by pressing the rear drill chuck sleeve (b) to the drill chuck.

Now you can put the appropriate bit into the integrated magnetic bit holder (10).

In order to mount the drill chuck again you have to put it on the bit holder and turn it a little until it can be defered completely. Lock the drill chuck by pushing the drill chuck sleeve (b) to the direction of the machine.

9. Technical data

Voltage supply:	10.8 V d.c. / 2.0 Ah Li-Ion
Idle speed:	0-400/0-1400 rpm
Torque settings:	18+1
Max. torque:	25 Nm
Forward and reverse rotation:	yes
Chuck clamping capacity:	0.8-10 mm
Battery charging voltage:	12.5 V d.c.
Battery charging current:	1500 mA
Mains voltage for charger:	100-240 V~/50-60 Hz
Charging time:	100 min

Sound and vibration

Sound and vibration values were measured in accordance with EN 60745-1, EN 60745-2-1, EN 60745-2-2.

L_{pA} sound pressure level	61.8 dB(A)
K_{pA} uncertainty	3 dB
L_{WA} sound power level	72.8 dB(A)
K_{WA} uncertainty	3 dB

Wear ear-muffs.

The impact of noise can cause hearing loss. Total vibration values (vector sum of three directions) determined in accordance with EN 60745-1, EN 60745-2-1, EN 60745-2-2.

Drilling in metal

Vibration emission value $a_h = 0.495 \text{ m/s}^2$
K uncertainty = 1.5 m/s^2

Screwing without hammer action

Vibration emission value $a_h < 2.5 \text{ m/s}^2$
K uncertainty = 1.5 m/s^2



Important!

The vibration value changes according to the area of application of the electric tool and may exceed the specified value in exceptional circumstances.

- Clean the equipment regularly with a moist cloth and some soft soap. Do not use cleaning agents or solvents; these could attack the plastic parts of the equipment. Ensure that no water can seep into the device.

12.2 Maintenance

There are no parts inside the equipment which require additional maintenance.

10. Repairs

Only use accessories and spare parts recommended by the manufacturer.

If the equipment should fail some day in spite of our quality controls and your maintenance, only let it repair by an authorized electrical specialist.

If the supply cord of the appliance is damaged, this has to be done by the manufacturer or his agent or electrician in order to avoid a safety hazard.

11. Environmental protection



Waste electrical equipment contains valuable materials and they do not belong to household waste.

We kindly ask you to help to protect the environment by returning this machine to a return point (if available) after reaching the end of its life.



Used batteries do not belong to household waste. There is the legal obligation to return batteries to appropriate recycling points.

12. Cleaning and maintenance

Always pull out the mains power plug before starting any cleaning work.

12.1 Cleaning

• Keep all safety devices, air vents and the motor housing free of dirt and dust as far as possible. Wipe the equipment with a clean cloth or blow it out with compressed air at low pressure.

• We recommend that you clean the device immediately each time you have finished using it.

DECLARATION OF CONFORMITY

Model: **32107**

Cordless drill/driver 10.8 V

KRAFTWERK Sàrl, 25 rue due Stade, F-67870 Bischoffsheim

Declares under sole responsibility that the product to which this declaration relates is in conformity with the following standard(s) or other normative document(s):

EN 55014-1: 2006+A1/2009+A2/2011

EN 55014-2: 1997+A1/2001+A2/2008

EN 60745-1: 2009+A11/2010

EN 60745-2-1: 2010

EN 60745-2-2: 2010

EN 60335-1: 2012+A11/2014

EN 60335-2-29: 2004+A2/2010

EN 62233: 2008

Following the provisions of Directive(s)
Machinery Directive:

2014/30/EU

2006/42/EC

2014/35/EU

Bischoffsheim, 28/01/2018



Alexander Pieper
CEO

WARRANTY

We do not take responsibility for any damage caused by misuse or any use that is not in compliance with the safety standards described herein.

CUSTOMER SERVICES

Contact your local importer of your specialized dealer to obtain address of our service department.

**FROM DATE OF PURCHASE RECEIPT
2 YEAR GUARANTEE
ON MATERIAL OR PRODUCTION DEFECTS**

KRAFTWERK®

FAVORITE TOOLS SINCE 1979

KRAFTWERK Europe AG
Mettlenbachstrasse 23
CH-8617 Mönchaltorf
Switzerland
Tel. +41-44 949 40 50

KRAFTWERK Sàrl.
25, rue du Stade
F - 67870 Bischoffsheim
France
Tel. +33-388 48 64 50

www.kraftwerktools.com